

Vibration Plate Manual



Please read this user manual carefully before use of this product!

PARTS



Remote Control



Resistance Bands



Power cord

PRODUCT SPECIFICATIONS

UNIT SPECS

Size:	23.6" x 14.2" x 4.7"
Net Weight:	13.9 lbs
Power:	200 W
Voltage:	110-120V, 60 HZ
Maximum User Weight:	330 lbs
Speed Levels:	1-120
Automatic Mode Programs:	P1 - P5
Operating Temperature:	14-95 °F
Storage Temperature:	-4-104 °F
Auto Shutoff Time:	10 minutes

MADE IN CHINA

FAQ

Quickly troubleshoot simple issues you might experience using the table below.

ISSUE	POSSIBLE REASON	HOW TO RESOLVE
THE MACHINE NOT WORKING.	Machine is not turned on.	Flip the power switch on the front of the machine to the ON position.
	The control panel is not on.	Press the On/Off button on the remote control to turn on the control panel.
THE MACHINE STOPPED WORKING SUDDENLY.	The vibration plate automatically shuts off after the set working time.	Turn the machine on again to begin a new workout program.
	When the machine has been working for a long time, the motor shuts off for overheating protection.	Allow the machine to cool for at least 30 minutes before using again.
THE REMOTE CONTROL DOES NOT WORK.	The remote control is too far away from the infrared sensor on the control panel.	Point the remote control directly at the infrared sensor when in use. The effective distance is approximately 5 feet.
	Battery is installed incorrectly.	Check to see if the battery is installed per the polarity markings on the inside of the battery compartment.
	Battery is dead.	Replace dead battery with a new battery (AAA battery*2pcs).
CANNOT TURN MACHINE OFF USING REMOTE CONTROL OR CONTROL PANEL	The Vibration plate must be powered off via the Power switch.	Flip the Power switch on the front of the machine to the OFF position.

EASY-START SET UP GUIDE

1

INSERT BATTERIES IN THE REMOTE CONTROL

- Remove the back of the remote control and insert AAA battery*2pcs battery (does not contain).

NOTE: Be sure to insert the battery according to the polarity markings inside the battery compartment.

2

ATTACH THE RESISTANCE BANDS

- Locate the two short metal bars extending from the underside of the machine.
- Insert the end of a resistance band through one of the metal bars. Then thread the handle through and pull tight to secure the band.
- Repeat to attach the second resistance band to the machine.



3

POWER ON THE VIBRATION PLATE

- Insert the power cord firmly into the power jack on the front of the Vibration Plate.



NOTE: Press forcefully until you feel a click, which indicates that the cord is securely connected. The power cord fits tightly so it will not loosen during use.

- Plug the power cord into a standard electrical outlet.
- Flip the power switch to the ON position.

OPERATING INSTRUCTIONS

USING THE CONTROL PANEL

1.ON/OFF Button: After connecting the power cable press this switch to start the standby state.

2.Start/Stop Button: Press once to start the selected preset program manual mode. Press a second time to pause the workout. Press a third time to resume the workout.

3.Mode Button: Press the button to select manual or automatic mode.

4. Speed +/Time+ Button: Press the button to increase the vibration speed. The manual mode time can be adjusted in the standby state. (Pressing this button in automatic mode does not work)

5.Speed -/Time-Button: Press the button to decrease the vibration speed. The manual mode time can be adjusted in the standby state. (Pressing this button in automatic mode does not work)

6.Remote control signal reception.



⚠ WARNING

To reduce the risk of burns, fire, electric shock, serious injury or death, damage to the product or property:

- Only power the machine using the included power cord.
- Only plug the machine into a properly grounded wall outlet, installed by a certified electrician.
- Always unplug the power cord by pulling gently from the plug. Never unplug by pulling on the cord itself.
- Never operate the machine, plug in, or unplug the power cord with wet hands.
- Do not wrap the power cord around the machine. Do not squeeze or place heavy objects on top of the power cord. Never place the power cord near sharp objects.
- Only use and store indoors, away from moisture, dust, dirt, and heat sources. Do not use or store in high-temperature or high-humidity environments. Keep out of direct sunlight.

- Do not operate where aerosol products are used or where oxygen is administered.
- Keep the power cord, surge suppressor, and batteries away from all heat sources.
- Ensure remote control batteries are inserted according to the polarity marking in the battery compartment. Incorrect installation may cause battery leakage and corrosion. Avoid contact with all battery residues, clean the remote with a cotton swab, wash hands thoroughly, and dispose of old batteries properly.
- Only replace the remote control batteries with two new AAA batteries.
- Never leave the machine unattended while it is running or plugged in. Always unplug the power cord when the machine is not in use.
- Check the machine, power cord, and remote for damaged or loosened screws before each use. Tighten any loosened screws before use. Do not use if damaged, faulty, or defective.

⚠ WARNING

To reduce the risk of serious injury or death:

- Excessive exercise or overexertion can be damaging to your health. Always exercise within the intensity and time limits recommended by your doctor.
- Stop exercising immediately and consult your doctor if you begin to feel tired, faint, dizzy, or nauseous, or if you experience pain, irregular heartbeat, or shortness of breath.
- Do not use the product near swimming pools or other bodies of water.
- Never place your head or upper body directly on the machine.
- Do not use the machine with straight legs or arms, as the vibrations are directed to your bones and brain, which can be dangerous for your health. Always slightly bend your legs and arms.
- This product is for adult use only. Do not allow children to play with or on the machine; this product is not a toy.
- Keep children and pets away from the product at all times. Never leave children unattended in the same room with the product.
- This product is not intended for use by people with reduced physical, sensory, or mental capabilities unless supervised by a responsible adult.

SAFETY INSTRUCTIONS

Before using this product, read all safety warnings and operating instructions. Failure to do so may result in serious injury or death, or damage to the product or property.

Keep this manual in a safe place for future reference.

RECOMENDATIONS

Consult with a medical professional before beginning a new exercise program to determine your appropriate fitness intensity and duration. Your physician can help determine if you have any physical limitations that could create a health risk or prevent you from properly using this product; some exercise programs or fitness products may not be appropriate for all people. Do not use this device if you:

- Are, or suspect you may be, pregnant, or if you have recently given birth.
- Have arrhythmia, severe cardiac disease, heart failure, deep-vein thrombosis, deep thrombophlebitis, erysipelas, or pulmonary edema.
- Have epilepsy or seizures, dementia, severe diabetes, or severe diabetic neuropathy.
- Have vertigo, positional dizziness, or balance impairments, or if you are taking drugs that affect balance.
- Have acute migraines, retinal detachment, acute rheumatoid arthritis, or severe joint disease.
- Have an orthopedic condition, spinal injury, osteoporosis, fracture, herniated or slipped disc, abnormal vertebra, spinal canal stenosis, Spondylosis, gliding Spondylolisthesis, ankylosing or cervical spondylitis, chronic back pain, sciatica, or other condition/disorder affecting the back or spinal column.
- Have recently had surgery or LASIK or PRK eye surgery.
- Have a medical implant, such as a pacemaker, cochlear implant, chest stent, ECG, joint replacement, intrauterine device, plate, pin, or rod.
- Are injured, ill, or if you have an open wound, a fever, or acute inflammation
- Have a gallstone or a kidney or bladder stone.

Consult your physician before using this product if you:

- Have heart disease or vascular disease, a blood circulation disorder, chronic hypertension, abnormal blood pressure, or if you are receiving treatment to normalize your blood pressure.
- Have a tumor or cancer, or if you suspect you may have cancerous lesions.
- Take painkillers or medicine to regulate your blood sugar.
- Are under the care of a physician for a serious health condition or have any concerns about your health.

⚠ WARNING: CHOKING HAZARD

Children under 3 years old can choke or suffocate on small parts.

⚠ WARNING: BATTERY INGESTION HAZARD

Battery ingestion is extremely dangerous and can cause severe injury and even death. Never allow children to play with batteries and always keep batteries out of reach. If a battery is ingested, seek immediate medical attention.

REMOTE DESCRIPTION

1. Standby Button: Power on, "----" is displayed, indicating that the machine is powered on normally. Press this button, and the value will be displayed on the display. The machine is in standby mode.

(Note: This button is not a power off button!!)

2. START Button: Press this button in the standby state to start the machine.

3. High Speed Button: Press the button to increase vibrations.

4. Low Speed Button: Press the button to decrease vibrations.

5. Time- Button: Press the button to reduce workout time (does not work with preset workouts).

6. Time+ Button: Press the button to increase workout time (does not work with preset workouts)

7. Mode Button: Press the button to quickly switch between preset exercises. (P1-P5)


8. Music: Previous song

9. Music: Next song

10. Walk Button: Press the button to set speed to 30.

11. Run Button: Press the button to set speed to 60.

12. Sprint Button: Press the button to set speed to 90.



Bluetooth: Turn on Bluetooth, search for "Hitgo V1"

CREATE A CUSTOM WORKOUT

Manual mode (which is the default mode) allows you to create a workout with custom time and speed.

Use the remote control to begin a 'manual mode' workout

1. Press the Power button to turn the control panel on to enter 'standby mode.' Manual mode is selected by default and "----" appears in the time window (the default time is 10 minutes, You can add time to your workout, up to 15 minutes)
2. Press the ON button to begin the manual mode workout. Press the Time +/- buttons on the remote control to adjust the working
3. Time from 1-15 minutes (in 1-minute increments) if desired. The default time is 10 minutes. Your selected time is shown in the time window, which counts down as the workout progresses. The time may be adjusted at any point during a workout.
4. Press the Speed +/- buttons to increase or decrease the vibration speed (from level 1-120, in increments of 1) if desired. The default speed level is 1. The speed may be adjusted at any time during the workout.
5. Press the Walk, Run, and Sprint buttons at any time in the manual mode workout to toggle through the speed options, 30, 60 and 90.
6. You may press the OFF button at any time to pause the workout before the working time ends. Press the Start button to resume the workout. The workout will stop automatically when the set working time is complete.
7. Always press the Power button to turn off the control panel, and flip the power switch to the OFF position.

NOTE: You may adjust the working time and vibration speed at any time during a manual program.

SETUP TIPS

1. Place the vibration plate on a level, non-slip floor. You may put an exercise mat under the machine to protect your carpet or other flooring. and/or reduce noise.
2. Set up the vibration plate in an area with at least 7 feet of clearance on all sides of the machine.
3. Plug the power cord into an easily accessible wall outlet so that you can remove the power cord immediately if there is a problem.

EXERCISE TIPS

1. Beginners should stand on the machine with their feet close together. Slowly increase the difficulty by standing with your legs further apart.
2. Start slow and easy, with 5 to 10-minute workouts.
3. Work your way up to longer, more challenging workouts over several weeks.
4. Long-term use will help you reach your fitness goals.
5. Always wear appropriate athletic clothing and shoes. Appropriate clothing should be comfortable and allow you to move freely.
6. You can amplify the vibrations by removing your shoes and socks.
7. Do not wear socks or slippers while using as this could cause you to slip. Do not wear jewelry, belts, loose or baggy clothing, or other accessories that could get caught and cause an accident or injury.
8. Remove cell phones and other valuables, as well as any sharp objects from your hands and pockets before using the Vibration Plate.
9. Warm up before using and cool down at the end of your workout.
10. Make sure to take sufficient breaks between exercises.
11. Breathe evenly, Exhale during exertion; inhale after exertion.
12. Perform all exercises with smooth, even movements.
13. We recommend placing a towel or training mat on top of the machines sitting, lying, or using your hands or arms on the machine.
14. Drink plenty of water before and after exercise.
15. Do not use on a full stomach; wait at least 80 minutes after eating to begin exercise.

TIPS FOR USING THE VIBRATION PLATE

SAFETY TIPS

1. Do not get on or off the unit until it is completely stopped.
2. Use the remote control to adjust the workout once exercise has begun.
3. Using the control panel while the machine is moving could cause an accident or injury.
4. Always stand on the machine with your back straight, your knees slightly bent, your heels slightly lifted and your arms bent.
5. Do not use the machine with straight legs or arms, as the vibrations are directed to your bones and brain, which can be dangerous for your health. If you feel vibrations in your eyes, vocal cords, or other parts of your head, you are not standing on the machine correctly and should shift your position immediately.
6. Never place your head or upper body directly on the machine. Never jump on or jump off the machine. Never attempt to turn around on the machine while it is in motion. Do not quickly lean back or change position; the machine is in motion
7. Stop exercising immediately and contact your doctor if you feel tired dizzy nauseous, or if you experience pain, difficulty breathing, or abnormal heart rate
8. Never perform other activities while using the machine as this could cause accidents or injury
9. Make sure your body is used to the vibration before you sit on the machine.
10. Do not use after drinking alcohol or taking medication that could affect your balance or make you sleepy.
11. Never allow more than one person to stand on the unit.



BEGIN A PRESET WORKOUT PROGRAM

In automatic mode, you may select from 5 preset workout programs. Use the remote control to begin a preset workout program:

1. Press the Power button to turn the control panel on to "Standby Mode. Manual mode is selected by default and "----" appears in the Time Window.
 2. Press the P button to toggle through the 5 preset programs in order: P1-P5. Your selected preset program shows on the display
 3. Press the Start button to begin the selected preset program.
 4. You may press the Pause button at any time to pause the workout before the working time ends. Press the Start button to resume the workout. The workout will stop automatically when the set working time is complete
- NOTE: You can not adjust the working time and vibration speed during the preset program.

EXERCISE QUICK START GUIDE

HOW TO BEGIN

It's a good idea to start slow and easy with your Vibration plate as it can take time to get used to how vibration plates move and feel. We recommend you follow the workout guide below--building from beginner to advanced over several weeks.

Auto Program

Program	Speed Level									
	10min	9min	8min	7min	6min	5min	4min	3min	2min	1min
P1	5	10	15	20	25	27	35	40	25	15
P2	2	5	7	10	12	15	35	25	20	15
P3	30	35	35	25	35	30	40	30	32	26
P4	50	56	60	68	76	80	90	70	56	60
P5	80	70	52	80	60	80	80	92	99	80

STANDING POSITIONS



CLEANING AND STORAGE

WARNING: Always unplug the power cord and allow the machine to before cleaning, moving, or storing. Use a slightly damp cloth to wipe away dirt or moisture.

A WARNING: Do not allow water or other liquids to come into contact with the device.

Do not immerse the device in water or other liquids.

Do not use harsh detergents or abrasive, solvent, or chemical cleansers. Store in a cool, dry, indoor location.

Store in a well-ventilated area, free of dust, and out of direct sunlight.

When storing for a long time, remove the batteries from the remote control and cover the machine to keep out dust and dirt.

Do not attempt to disassemble or repair; the device contains no user-serviceable parts.

This product is intended for use indoors (not outside) and at home. Dispose of the product and all parts according to local and federal regulations.

Unplug the device immediately in the event of a power failure. Keep sharp objects away from the product to avoid damaging it.

Use Method

1: Stand upright on the product, with two legs apart, the distance of two legs is mostly the same as width of shoulder. This posture can exercise waists and buttocks to relieve stress on waists and sculpture beautiful curve of buttocks.



2: Stand on the product with two legs apart and knee bent. The posture can exercise thighs to sweep pain and soreness, improve blood circulation, and reduce fat deposit.



3: Seat on chair or sofa, with feet put on the product, This posture can exercise both thigh and calf.



4: Seat on carpet, with two legs put on the product. This posture can exercise leg.



5: Kneel on the carpet, put hands onto the products, with body lean forward, this posture can exercise shoulder joint and arms.



It is recommended to use the machine on flat floors or tiles, and avoid using it on uneven or soft surfaces.